



### GRAND LIVINA (L10N/L11)

Belt Fan & Alt  
Oil Filter  
Air Filter  
Spark Plug  
Filter Air Cabin  
Engine Oil  
Brake Fluid  
Long Life Coolant  
Mtf  
Atf  
Cvtf  
Gasket Ins Carb  
Gasket Egr C/valve  
Gasket Int Manifold  
Gasket Oil Pan Plug  
Brake Pad  
Brake Shoe Set  
Piston Kit M/cyl Brake  
Disc Brake Rotor Fr  
Seal Kit Fr Disc Brake  
Hose Assy Brake Fr Rh  
Hose Assy Brake Fr Lh  
Disc Assy-clutch  
Clutch Cover  
Cylinder Assy Cl/opr  
Dust Boot Kit-repair,inner  
Dust Boot Kit-repair,outer  
Link Compl-transverse,rh  
Link Compl-transverse,lh  
Bush Transv Link  
Strut Kit Frt Susp Rh  
Strut Kit Frt Susp Lh  
Shock Absorber Rr  
Insulator Eng Mtg Frt  
Engine Mount Insulator  
Fuel Pump  
Water Pump  
Thermostat  
Radiator  
Cooling Fan  
Radiator Hose  
Ignition Coil  
Seal Oil Crank Shaft Rr  
Gasket Rocker Cover

Seal Oil Crank Shaft Fr  
Cap A Radiator Filler  
Sensor Assy-o2 Lh  
Alternator  
Blade Assy W/shield Driver  
Blade Assy W/shield Assist  
Compressor A/c  
Glass Mirror Rh  
Glass Mirror Lh  
Evaporator Assy Cooler  
Clutch Assy Compressor  
Boot Kit P/strg Rh  
Socket Tie Rod Otr  
Socket Tie Rod Inn  
Bush Stabilizer  
Rod Assy Conn Stab  
Fuse (Small) 10a  
Fuse (Small) 15a  
Bohlamp Rem  
Bohlamp Sign  
Bohlamp Mundur  
Bulb Headlamp  
Battery Key Alarm  
Bulb Fog Lamp  
Refill-wiper Blade,driver  
Refill-wiper Blade Assist  
Grommet Screw  
Clip  
Clip-trim  
Dowel Camshaft  
Head Assy Cylinder  
Gasket-cylinder Head  
Pan Assy Oil  
Brkt-eng Mtg,rh  
Bracket-alternator  
Brkt Assy-eng Mtg,fr  
Support-engine Mounting,lh  
Valve Assy Control  
Insulator Pcv Valve  
Hose-blowby Gas  
Bearing-connecting Rod  
Bushing Crank  
Pulley Assy Cr/shaft  
Pilot Conv  
Sprocket Cr/shaft  
Guide-chain,tension Side

Seal Oil Viv Stem  
Collet Valve Lock  
Cover A Viv Rocker  
Hose Water  
Gasket Egr C/valve  
Gasket Adapter  
Clip-hose  
Release Quick  
Cleaner Assy Air  
Air Cleaner Cover  
Duct-air  
Mtg-air Clnr,rub  
Duct Assy A/cleaner  
Injector Assy Fuel  
Tube Breather  
Tube Assy-fuel Feed  
Mfr Assy-exh,sub  
Insulator Exh Mtg  
Gasket Exh Pipe  
Bearing Seal  
Gasket Water Pump  
Valve A/water Ctr  
Shroud Assy  
Motor Assy Fan  
Shroud Assy-w/d  
Hose-radiator,lower  
Hose A/t Cooler  
Tank Assy-reserve  
Cap Tank Reserv  
Hose Reserve Tank  
Sensor Assy Temp  
Sensor Assy-o2  
Control Unit Eng  
Crankshaft Position  
Harness Eng Room  
Terminal Assy-battery\_16.60mm  
Cap-terminal  
Link Fusible 50a  
Holder Link Fusible  
Cover-fusible Link Holder  
Bar Battery  
Combination Meter  
Sender Unit Fuel  
Switch Oil Pressure  
Sw Assy-stop Lamp  
Element Lighter

Switch Assy-power Window,main  
Switch Assy-power Window,assis  
Switch Assy T/sign  
Sw Assy-strg  
Relay Assy Horn  
Lamp Assy Head Rh  
Housing Assy H/lamp Rh  
Cover Socket  
Lamp Assy Head Lh  
Housing Assy H/lamp Lh  
Lamp Assy Side Flasher  
Bulb Lo H11 12v/55w  
Lamp Assy-room  
Lamp Assy Licence  
Lamp Assy Back Rh  
Lamp Assy Back Lh  
Lamp Assy Rr Comb Rh  
Lamp Assy Rr Comb Lh  
Cover-high Mounting Stop Lamp  
Motor Blower  
Door Inlet Blower  
Base Control  
Control Unit-ipdm Engine Room  
Cont Assy-key Less  
Switch Assy-smart Keyless  
Arm Assy Rr Wdw Wiper  
Cover Rr Wiper Arm  
Cover-wiper Arm  
Tank Assy W/washer  
Cap W/s Washer Tank  
Pump Assy-washer  
Nozzle Assy-washer,lh  
Nozzle Assy-washer,rh  
Hose Assy Clutch  
Gasket-oil Pan  
Gasket Side Cover  
Bearing Needle  
Plate A Drive  
Switch Inhibitor  
Sensor Assy Revolution  
Solenoid A/t Control  
Pinion Speedometer  
Cable Assy-auto Tran  
Seal-oil,differential  
Shaft Assy Frt Drv Rh  
Shaft Assy Frt Drv Lh

Joint Assy-inner  
Hub Assy Frt Wheel  
Valve-air  
Ornament Disc Wheel  
Caliper Assy-fr Rh W  
Caliper Assy-fr Lh W  
Piston Cylinder Brk  
Hub Assy-rear  
Cyl Assy Rr Wheel  
Cap Assy M/cyl Tank  
Spr-lock,brake Hose  
Tube Assy-brake,front Rh  
Tube Assy-brake,front Lh  
Insulator  
Tube Assy Brake  
Valve Assy-load Sens  
Pedal Compl-clutch,w  
Stopper-rubber  
Gear A Steering  
Rack Steering Gear  
Retainer-steering Gear  
Wheel Assy-strg  
Pad-horn  
Shaft Assy Strg Col  
Spring-front  
Stay Assy-fr Susp Mbr  
Stabilizer Bar Frt  
Spring-rear Suspension  
Bushing Shockabsorber  
Brkt-fr Bmpr,rh  
Brkt-fr Bmpr,lh  
Bracket-front Bumper Side,rh  
Bracket-front Bumper Side,lh  
Finisher Frt Fascia Rh  
Finisher Frt Fascia Lh  
Cover-bumper Bracket  
Grille Radiator  
Grommet  
Guide-air,fr Rh  
Guide-air,fr Lh  
Air Guide Front  
Emblem Rad Grille  
Over Fender-front,rh  
Over Fender-front,lh  
Protr Assy-fr Fdr,rh  
Protr Assy-fr Fdr,lh

Fin Assy-fr Fdr,rh  
 Fin Assy-fr Fdr,lh  
 Male Assy Hood Lock  
 Cable Assy-hood Lock Control  
 Rod-hood Support  
 Rub Seal Hood F  
 Clip Hood Ins  
 Seal-cowl Top  
 Cover Cowl Top  
 Cover-front Fender,rh  
 Cover-front Fender,lh  
 Insul-dash Lwr,fr  
 Insulator Dash Lower  
 Pocket Deck  
 Clip-lwr Cover  
 Finisher-instrument Lower  
 Lid Assy-fuse Block  
 Moulding Assy-roof Side,rh  
 Moulding Assy-roof Side,lh  
 Grip Assy-asst  
 Brkt Assy-tunnel Stay  
 Cover Assy-fr Under  
 Mudguard Sill Ctr Rh  
 Clip-roof Side Mldg  
 Garnish-center Pillar,lower Rh  
 Welt Body Side Fr  
 Cover Assy-rr Fdr,rh Unpainted  
 Cover Assy-rr Fdr,lh Unpainted  
 Cable Compl-fuel Opnr  
 Glass Run-fr Door Wdw,rh  
 Glass Run-fr Door Wdw,lh  
 Bracket-outside Handle,rh  
 Brkt Assy-fr Door O/  
 Eschuteon Out  
 Gasket-door O/s Hand  
 Grom  
 Fin Assy-fr Door,rh  
 Fin Assy-fr Door,lh  
 Cap Pull Handle  
 Glass Run-rr Door Wdw,rh  
 Glass Run-rr Door Wdw,lh  
 Glass Run Dr Low Frt  
 Glass Run Dr Low Rr  
 Lock & Remote Control Assy-rr Door  
 Escutcheon-outside Handle,lh  
 Moulding-rear Door Outside,rh  
 Moulding-rear Door Outside,lh  
 Fin Assy-rr Door,rh  
 Fin Assy-rr Door,lh  
 Mould Rr Bumper  
 Energy Absorber-rear Bumper  
 Bracket-rear Bumper Side,rh  
 Bracket-rear Bumper Side,lh  
 Knob-reclining Device  
 Hook Cushion Rr Seat  
 Lock Assy Back Door  
 Cable Assy-back Door Opener  
 Striker-back Door Lock  
 Fin Assy Back Door  
 Weatherstrip Back Door  
 Emblem Rr Back Dr  
 Emblem Back "Grand Livina"  
 Emblem-back "1.5 Xv"  
 Emblem Rear Grand Livina  
 Fin Assy-back Door  
 Cover-back Door Wipe  
 Handle-pull,back Door  
 Condenser Assy  
 Mounting Rob Cond  
 Tank Assy Liquid  
 Sensor Assy-pressuree  
 Valve Assy Expansion  
 Hose Flex Low  
 Over Fender-rear Rh  
 Over Fender-rear Lh  
 Bracket Licence Plate

Mirror Assy-door,rh  
 Mirror Assy-door,lh  
 Cover-mirror Body,rh  
 Cover-mirror Body,lh  
 Sunvisor Assy-rh  
 Sunvisor Assy-lh  
 Panel-console Switch (C)  
 Bulb Indicator  
 Key Set Ig/strg Lock  
 Bearing Set C/rod  
 Bushing Set Us-0.25  
 Remote Control Roof Rm202  
 Remote Control Hu  
 Sensor Eye  
 Back Sonar White  
 Sensor Diagnosis A/bag  
 Repair Kit Dust Boot  
 Hardware Kit Frt Disc  
 Mudguard Rr Rh  
 Mudguard Rr Lh  
 Key Blank Master  
 Lid Assy Trunk  
 Safety Triangle  
 Emblem 1.5 Xv Auto  
 Mirror Kit W/o Lamp Rh  
 Mirror Kit W/o Lamp Lh

### DATSUN (K2)

Belt Fan & Alt  
 Oil Filter  
 Air Filter  
 Spark Plug  
 Filter Air Cabin  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Mtf  
 Gasket Ins Carb  
 Gasket Int Manifold  
 Nut Lock Rear Wheel  
 Cap-hub,rear Wheel  
 Gasket Oil Pan Plug  
 Brake Pad  
 Brake Shoe Set  
 Brake Master Cylinder  
 Disc Brake Rotor Fr  
 Seal Kit Fr Disc Brake  
 Hose Assy Brake Fr Rh  
 Hose Assy Brake Fr Lh  
 Disc Assy-clutch  
 Clutch Cover  
 Cylinder Assy Cl/opr  
 Dust Boot Kit-repair,inner  
 Dust Boot Kit-repair,outer  
 Link Compl-transverse,rh  
 Link Compl-transverse,lh  
 Bush Compr Rod Fr  
 Strut Kit Frt Susp Rh  
 Strut Kit Frt Susp Lh  
 Shock Absorber Rr  
 Insulator Eng Mtg Frt  
 Engine Mount Insulator  
 Fuel Pump  
 Water Pump  
 Thermostat  
 Radiator  
 Cooling Fan  
 Radiator Hose  
 Ignition Coil  
 Seal Oil Crank Shaft Rr  
 Gasket Rocker Cover  
 Seal Oil Crank Shaft Fr  
 Cap A Radiator Filler  
 Sensor Assy-o2 Lh  
 Alternator

Blade Assy W/shield Driver  
 Compressor A/c  
 Evaporator Assy Cooler  
 Boot Kit P/strg Rh  
 Socket Tie Rod Otr  
 Socket Tie Rod Inn  
 Fuse 10 A  
 Fuse 15 A  
 Bohlamp Rem  
 Bohlamp Sign  
 Bohlamp Mundur  
 Bulb Headlamp  
 Refill-wiper Blade,driver  
 Clip  
 Bmpr-f/filler Lid  
 Plug Body Sill  
 Gasket Kit-engine Repair  
 Dowel Camshaft  
 Dowl Cyl Head Cvr  
 Water Outlet  
 Valve Assy Control  
 Insulator Pcv Valve  
 Hose-blowby Gas  
 Shaft Idle Pulley  
 Cover-idler Pulley  
 Spacer Idler Pulley  
 Collar-idler Pulley  
 Ring Set Piston Std  
 Bearing-connecting Rod  
 Bearing Cr/s  
 Pulley Assy Cr/shaft  
 Tensioner Assy-chain  
 Guide-chain,tension Side  
 Seal Oil Vlv Stem  
 Collet Valve Lock  
 Cover A Vlv Rocker  
 Chamber Assy-throttle  
 Clip-hose  
 Air Cleaner Cover  
 Body Assy-air Cleaner  
 Duct-air  
 Injector Assy Fuel  
 Cap Assy-filler  
 Lever Assy Accel  
 Spr Special  
 Insulator Exh Mtg  
 Gasket Water Pump  
 Seal-radiator,upper  
 Seal Radiator Rh  
 Seal Radiator Lh  
 Hose-radiator,lower  
 Insulator Rad Mtg  
 Tank Assy-reserve  
 Sensor Booster  
 Sensor Assy Temp  
 Brush Assy  
 Bearing Ball Rr  
 Motor Starter  
 Control Unit Eng  
 Crankshaft Position  
 Harness Eng Room  
 Cover-batt Conn  
 Holder Link Fusible  
 Frame-battery Fix  
 Switch Oil Pressure  
 Sw Assy-stop Lamp  
 Power Socket Assy  
 Switch Assy-door  
 Switch Assy-power Window,assis  
 Horn Assy L/tone  
 Relay Assy Horn  
 Socket Assy-clearance Lamp  
 Bulb Head Lamp  
 Bulb Lamp Assy-map  
 Lamp Assy Licence  
 Body Assy-rear Comb Rh

Body Assy-rear Comb Lh  
 Motor Blower  
 Control Unit-ipdm Engine Room  
 Cover Usm  
 Drive Assy-windshield Wiper  
 Link Assy-wiper  
 Connector-hose  
 Switch Rev Lamp  
 Neutral Position Switch  
 Seal Oil Input  
 Cable Assy Cotrol  
 Shaft Assy Frt Drv Rh  
 Shaft Assy Frt Drv Lh  
 Joint Assy-inner  
 Spindle Knuckle Rh  
 Spindle Knuckle Lh  
 Bearing Assy-front Wheel  
 Valve-air  
 Cap Disc Wheel  
 Ornament Disc Wheel  
 Spindle-rear  
 Hub Assy-rear  
 Brake Assy-drum,rear Rh  
 Brake Assy-drum,rear Lh  
 Spr-lock,brake Hose  
 Insulator  
 Gear & Link Assy Strg  
 Pad-horn  
 Seat Assy-front Spring,upper  
 Bumper Assy Bound  
 Stopper-insulator  
 Seat Spring Rr  
 Hanger Assy-spare Tire  
 Bracket-front Bumper Side,rh  
 Bracket-front Bumper Side,lh  
 Cover-fr Bumper Grille,lower  
 Protr Assy-fr Fdr,rh  
 Protr Assy-fr Fdr,lh  
 Hinge Assy Hood Rh  
 Hinge Assy Hood Lh  
 Male Assy Hood Lock  
 Grom Hood Rodd  
 Seal-cowl Top  
 Mbr Assy-strg  
 Ventilator Assy  
 Insulator-heat,front Floor  
 Drafter-air  
 Guard Drafter Air  
 Tape-rear Fender,rh  
 Tape-rear Fender,lh  
 Cover-front Door Corner,inner Rh  
 Cover-front Door Corner,inner Lh  
 Lock & Remote Control  
 Knob Door Lock  
 Handle Assy-font Door Os, Rh  
 Handle Assy-front Door Os, Lh  
 Handle Assy-door inside,rh  
 Handle Assy-door inside,lh  
 Regulator Assy-door Window,rh  
 Regulator Assy-door Window,lh  
 Motor Assy-regulator,rh  
 Motor Assy-regulator,lh  
 Handle Assy-door Window Regula  
 Rubber Bumper  
 Cover-fr Door Corner,inner Rh  
 Cover-fr Door Corner,inner Lh  
 Glass Run-rr Door Wdw,rh  
 Glass Run-rr Door Wdw,lh  
 Hinge Assy-rear Door,upper Rh  
 Hinge Assy-rear Door,upper Lh  
 Hinge Assy Front Door Lower  
 Hinge Assy Front Door Upper  
 Check Assy Rr Dr  
 Moulding-rear Door Outside,rh  
 Cable Assy-trunk Lid Opener  
 Hook Cushion Rr Seat

Knob-seat Back  
 Lock Assy Back Door  
 Striker-back Door Lock  
 Weatherstrip Back Door  
 Bumper-rubber  
 Emblem-back Door (Go)  
 Bracket-condensor  
 Hose Flex Low  
 Holder Sunvisor  
 Bearing Set C/rod  
 Bearing Set Cr/s Std  
 Module Parking  
 Cup Kit Rr W/cyl  
 Emblem Nusanlara  
 Emblem Panca  
 Bracket-front Fender  
 Bracket-canister  
 Brkt Assy-bat  
 Lid Assy-fuel Filler  
 Safety Triangle

### MARCH (K13N)

Belt Fan & Alt  
 Oil Filter  
 Air Filter  
 Spark Plug  
 Filter Air Cabin  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Mtf  
 Gasket Ins Carb  
 Gasket Int Manifold  
 Gasket-adaptor  
 Nut Lock Rear Wheel  
 Cap-hub,rear Wheel  
 Gasket Oil Pan Plug  
 Brake Pad  
 Brake Shoe Set  
 Brake Master Cylinder  
 Disc Brake Rotor Fr  
 Seal Kit Fr Disc Brake  
 Hose Assy Brake Fr Rh  
 Hose Assy Brake Fr Lh  
 Disc Assy-clutch  
 Clutch Cover  
 Cylinder Assy Cl/opr  
 Dust Boot Kit-repair,inner  
 Dust Boot Kit-repair,outer  
 Link Compl-transverse,rh  
 Link Compl-transverse,lh  
 Bush Transv Link  
 Strut Kit Frt Susp Rh  
 Strut Kit Frt Susp Lh  
 Shock Absorber Rr  
 Insulator Eng Mtg Frt  
 Engine Mount Insulator  
 Fuel Pump  
 Water Pump  
 Thermostat  
 Radiator  
 Cooling Fan  
 Radiator Hose  
 Ignition Coil  
 Seal Oil Crank Shaft Rr  
 Gasket Rocker Cover  
 Seal Oil Crank Shaft Fr  
 Cap A Radiator Filler  
 Sensor Assy-o2 Lh  
 Alternator  
 Blade Assy W/shield Driver  
 Blade Assy W/shield Assist  
 Compressor A/c  
 Glass Mirror Rh  
 Glass Mirror Lh

Evaporator Assy Cooler  
Clutch Assy Compressor  
Boot Kit P/strg Rh  
Socket Tie Rod Otr  
Socket Tie Rod Inn  
Fuse 10 A  
Fuse 15 A  
Fuse 20 A  
Bohlamp Rem  
Bohlamp Sign  
Bohlamp Mundur  
Bulb Headlamp  
Battery Key Alarm  
Bulb Fog Lamp  
Refill-wiper Blade,driver  
Refill-wiper Blade Assist  
Clip  
Bmpr-f/filler Lid  
Plug Body Sill  
Dowel Camshaft  
Dowl Cyl Head Cvr  
Water Outlet  
Pan Assy Oil  
Plug Blind  
Brkt-eng Mtg,rh  
Valve Assy Control  
Insulator Pcv Valve  
Shaft Idle Pulley  
Cover-idler Pulley  
Spacer Idler Pulley  
Collar-idler Pulley  
Ring Set Piston Std  
Bearing-connecting Rod  
Bearing Cr/s  
Bushing Crank  
Pilot Conv  
Plate A Drv W/gear  
Guide-chain,tension Side  
Cover A Vlv Rocker  
Tube-anti Evaporation Control  
Cleaner Assy Air  
Body Assy-air Cleaner  
Duct-air  
Injector Assy Fuel  
Packing-fuel Gauge  
Lever Assy Accel  
Tube Assy Exh Frt  
Spr Special  
Gasket Water Pump  
Shroud Assy W/motor  
Shroud Assy  
Seal Radiator Rh  
Seal Radiator Lh  
Insulator Rad Mtg  
Tank Assy-reserve  
Cap Tank Reserv  
Air Fuel Ratio Sensor  
Motor Starter  
Switch Magnetic  
Control Unit Eng  
Crankshaft Position  
Sender Unit Fuel  
Sw Assy-stop Lamp  
Switch Assy-door  
Horn Assy L/tone  
Lamp Assy Head Rh  
Lamp Assy Head Lh  
Lamp Assy Rr Comb Rh  
Lamp Assy Rr Comb Lh  
Bracket Fog Lamp Rh  
Bracket Fog Lamp Lh  
Resistance Elect  
Motor Blower  
Shaft-door,intake Blower  
Control Assy A/c  
Knob-control

Amplifier Assy-thermo  
Sensor Assy-thermister  
Switch Assy-remote  
Controller Assy  
Control Unit-ipdm Engine Room  
Cover Usm  
Controller Assy-power Steering  
Arm Assy Rr Wdw Wiper  
Arm Assy Wiper  
Connector-hose  
Gasket-oil Pan  
Piston Clutch  
A Gear 3rd M/s  
Cable Assy Cotrol  
Shaft Assy Frt Drv Rh  
Shaft Assy Frt Drv Lh  
Spindle Knuckle Rh  
Spindle Knuckle Lh  
Bearing Assy-front Wheel/ Hub  
Bearing Assy-front Wheel  
Valve-air  
Caliper Assy-fr Rh W  
Caliper Assy-fr Lh W  
Piston Cylinder Brk  
Spindle-rear  
Cyl Assy Rr Wheel  
Adjuster Assy  
Valve Assy-check  
Gear & Link Assy Strg  
Bush  
Wheel Assy-steering,less Pad  
Seat Spring Rr  
Beam Compl-rr Sulp  
Reinforce Frt Bmp  
Bracket-front Bumper Side,rh  
Bracket-front Bumper Side,lh  
Finisher Frt Fascia Rh  
Finisher Frt Fascia Lh  
Cover-bumper Bracket  
Grille Radiator  
Mounting-radiator Grille  
Protr Assy-fr Fdr,rh  
Protr Assy-fr Fdr,lh  
Male Assy Hood Lock  
Grom Hood Rodd  
Cover Cowl Top  
Panel & Pad Assy-instrument  
Finisher-instrument Lower  
Moulding Set W/shield  
Moulding Assy-roof Side,rh  
Moulding Assy-roof Side,lh  
Headlining Assy  
Insulator-heat,front Floor  
Drafter-air  
Protector-rear Fillet Rh  
Protector-rear Fillet Lh  
Finisher-rear Parcel Shelf  
Cover-front Door Corner,inner Rh  
Cover-front Door Corner,inner Lh  
Link-door Stopper  
Lock & Remote Control  
Bracket-outside Handle,rh  
Bracket-outside Handle,lh  
Regulator Assy-door Window,rh  
Regulator Assy-door Window,lh  
Motor Assy-regulator,rh  
Motor Assy-regulator,lh  
Tape-front Door Sash Rear,rh  
Tape-front Door Sash Rear,lh  
Moulding Frt Dr Otr Rh  
Moulding Frt Dr Otr Lh  
Fin Assy-fr Door,rh  
Fin Assy-fr Door,lh  
Weatherstrip-rear Corner,rh  
Weatherstrip-rear Corner,lh  
Glass Run-rr Door Wdw,rh

Glass Run-rr Door Wdw,lh  
Lock & Remote Control Assy-rr Door  
Escutcheon-outside Handle,lh  
Escutcheon-outside Handle,rh  
Tape-rr Door,rh  
Tape-rr Door,lh  
Moulding-rear Door Outside,rh  
Moulding-rear Door Outside,lh  
Plate Luggage Rear  
Bracket-rear Bumper Side,rh  
Bracket-rear Bumper Side,lh  
Knob-reclining Device  
Lock Assy Back Door  
Bumper-rubber  
Emblem Rr Back Dr  
Tank Assy Liquid  
Sensor Assy-pressuree  
Mirror Assy Inside  
Cover-mirror Body,rh  
Cover-mirror Body,lh  
Sunvisor Assy-rh  
Sunvisor Assy-lh  
Bulb Indicator  
Key Set Ig/strg Lock  
Bearing Set C/rod  
Bearing Set Cr/s Std  
Module Assy Alarm  
Repair Kit Dust Boot  
Hardware Kit Frt Disc  
Cylinder Assy M/brk  
Booster Assy-brake  
Key Blank Master  
Hinge Assy-front Door,lower Rh  
Hinge Assy-front Door,lower Lh

### X-TRAIL (T30)

Belt Fan & Alt  
Oil Filter  
Air Filter  
Spark Plug  
Filter Air Cabin  
Engine Oil  
Brake Fluid  
Long Life Coolant  
Mtf  
Atf  
Gasket Int Manifold  
Gasket Oil Pan Plug  
Brake Pad  
Brake Shoe Set  
Brake Master Cylinder  
Seal Kit Fr Disc Brake  
Disc Assy-clutch  
Clutch Cover  
Cylinder Assy Cl/opr  
Strut Kit Frt Susp Rh  
Strut Kit Frt Susp Lh  
Shock Absorber Rr  
Insulator Eng Mtg Frt  
Engine Mount Insulator  
Fuel Pump  
Water Pump  
Thermostat  
Radiator  
Radiator Hose  
Ignition Coil  
Seal Oil Crank Shaft Rr  
Gasket Rocker Cover  
Seal Oil Crank Shaft Fr  
Cap A Radiator Filler  
Blade Assy W/shield Driver  
Blade Assy W/shield Assist  
Glass Mirror Rh  
Glass Mirror Lh  
Socket Tie Rod Inn

Bush Stabilizer  
Rod Assy Conn Stab  
Fuse (Small) 3a  
Fuse (Small) 75a  
Fuse (Small) 10a  
Fuse (Small) 15a  
Fuse (Small) 20a  
Bohlamp Rem  
Bohlamp Sign  
Bohlamp Mundur  
Bulb Headlamp  
Battery Key Alarm  
Bulb Fog Lamp  
Refill-wiper Blade,driver  
Refill-wiper Blade Assist  
Clip  
Gasket Kit-engine Repair  
Tube-spark Plug  
Pan Assy Oil  
Tensioner Assy  
Ring Set Piston 0.20 (4)  
Bearing Cr/s  
Bearing Cr/s Std Gr O  
Flywheel Assy  
Cover Assy Front  
Duct-air  
Lever Assy Accel  
Gasket Exh Pipe  
Bearing Seal  
Valve A/water Ctr  
Tank Radiator Upper  
Shroud Assy W/motor  
Shroud Assy  
Bearing Ball Alt Frt  
Bar Battery  
Relay Ign  
Relay Assy Horn  
Lamp Assy Frt Sgn Rh  
Lamp Assy Frt Sgn Lh  
Lamp Assy Side Flasher  
Socket Bulb  
Lamp Assy Rr Comb Rh  
Lamp Assy Rr Comb Lh  
Resistance Elect  
Nozzle  
Seal Oil  
Sensor Assy Revolution  
Switch Rev Lamp  
Plate-cable Lock  
Hub Assy Frt Wheel  
Valve-air  
Ornament Disc Wheel  
Piston Cylinder Brk  
Rotor Disc Rr Brk  
Cylinder Assy M/brk  
Boot Kit P/strg  
Gear Sub Assy  
Cover Assy Cyl  
Seal Kit-power Steering Pump  
Hose Control  
Insulator Assy Strut Mtg  
Link Compl-radius Rod  
Link Parallel Frt Rh  
Link Parallel Frt Lh  
Link Parallel Rr  
Grille Radiator  
Protr Assy-fr Fdr,rh  
Protr Assy-fr Fdr,lh  
Hook Tonneau Cover Rh Grey  
Plate Luggage Rear  
Weatherstrip Back Door  
Bumper-rubber  
Mounting Rob Cond  
Compressor A/c  
Gasket Kit Vlv Grind  
Piston W/pin Gr 3

Bulb F/Imp H3 12v/55w  
Band Boot  
Key Blank Master

### NEW X-TRAIL (T31)

Belt Fan & Alt  
Oil Filter  
Air Filter  
Spark Plug  
Filter Air Cabin  
Engine Oil  
Brake Fluid  
Long Life Coolant  
Mtf  
Cvtf  
Gasket Ins Carb  
Gasket Oil Pan Plug  
Brake Pad  
Brake Shoe Set  
Seal Kit Fr Disc Brake  
Disc Assy-clutch  
Clutch Cover  
Cylinder Assy Cl/opr  
Strut Kit Frt Susp Rh  
Strut Kit Frt Susp Lh  
Shock Absorber Rr  
Insulator Eng Mtg Frt  
Engine Mount Insulator  
Fuel Pump  
Water Pump  
Thermostat  
Radiator  
Radiator Hose  
Ignition Coil  
Seal Oil Crank Shaft Rr  
Gasket Rocker Cover  
Seal Oil Crank Shaft Fr  
Cap A Radiator Filler  
Alternator  
Blade Assy W/shield Driver  
Blade Assy W/shield Assist  
Glass Mirror Rh  
Glass Mirror Lh  
Bush Stabilizer  
Rod Assy Conn Stab  
Fuse (Small) 10a  
Fuse (Small) 15a  
Fuse (Small) 20a  
Bohlamp Rem  
Bohlamp Mundur  
Bulb Headlamp  
Battery Key Alarm  
Bulb Fog Lamp  
Refill-wiper Blade,driver  
Refill-wiper Blade Assist  
Clip  
Clip-hose,spr Plate  
Gasket-water Outlet  
Buffer Assy-rr  
Tensioner Assy  
Ring Set Piston Std  
Bearing-connecting Rod  
Bearing Cr/s  
Bushing Crank  
Cover A Vlv Rocker  
Valve Assy-control  
Duct-air  
Mtg-air Clnr,rub  
Lever Assy Accel  
Tube Assy Exh Frt  
Spr Special  
Insulator Exh Mtg  
Gasket Exh Pipe  
Bearing Seal  
Ring Rubber

Hose-water,oil Cooler  
 Motor Assy Fan  
 Pulley Assy Alt  
 Bearing Ball Alt Frt  
 Bearing Ball Rr  
 Crankshaft Position  
 Link Fusible 50a  
 Sender Unit Fuel  
 Relay Ign  
 Switch Assy Wiper  
 Sw Assy-stop Lamp  
 Element Lighter  
 Switch Assy T/lid Opn  
 Switch Assy-power Window,assis  
 Horn Assy L/tone  
 Horn Assy H/tone  
 Lamp Assy Head Rh  
 Housing Assy H/lamp Rh  
 Lamp Assy Head Lh  
 Housing Assy H/lamp Lh  
 Bracket Assy-mount  
 Lamp Assy Back Rh  
 Lamp Assy Back Lh  
 Lamp Assy Rr Comb Rh  
 Lamp Assy Rr Comb Lh  
 Rim Assy Driving  
 Resistance Elect  
 Switch Assy-remote  
 Remote Control Assy  
 Switch Assy-smart Keyless  
 Nozzle  
 Cover Rr Wiper Arm  
 Hose Assy Washer  
 Pump Assy-washer  
 Gasket-oil Pan  
 Shaft Assy Frt Drv Rh  
 Shaft Assy Frt Drv Lh  
 Joint Kit Outer  
 Valve-air  
 Piston Cylinder Brk  
 Hub Assy-rear  
 Rotor Disc Rr Brk  
 Sensor A/anti Skid Rr  
 Gear & Link Assy Strg  
 Spring Seat  
 Insulator Assy Strut Mtg  
 Seat Spring Rr  
 Bumper Suspens  
 Link Compl-stab Rr,rh  
 Link Compl-stab Rr,lh  
 Reinforce Frt Bmp  
 Mldg Bmp Fr Rh  
 Mldg Bmp Fr Lh  
 Mldg Bmp Fr  
 Bracket-front Bumper Side,rh  
 Bracket Bmp Mtg  
 Finisher Frt Fascia Rh  
 Cover-bumper Bracket  
 Grille Radiator  
 Guide-air,fr Rh  
 Guide-air,fr Lh  
 Emblem Rad Grille  
 Protr Assy-fr Fdr,rh  
 Protr Assy-fr Fdr,lh  
 Mud Guard Frt Rh  
 Mud Guard Frt Lh  
 Hinge Assy Hood Rh  
 Hinge Assy Hood Lh  
 Bumper Hood  
 Cover Cowl Top  
 Cover-front Fender,rh  
 Cover-front Fender,lh  
 Panel & Pad Assy-instrument  
 Pocket Deck  
 Mudguard Sill Ctr Rh  
 Mudguard Sill Ctr Lh

Mud Guard Rr Rh  
 Mud Guard Rr Lh  
 Link-door Stopper  
 Grip Out Side  
 Eschuteon Out  
 Gasket-door O/s Hand  
 Tape-front Door Sash Rear,rh  
 Tape-front Door Sash Rear,lh  
 Moulding Frt Dr Otr Rh  
 Moulding Frt Dr Otr Lh  
 W/strip Frt Dr Rh  
 W/strip Frt Dr Lh  
 Mld Fr Dr Rh Low  
 Mld Fr Dr Lh Low  
 W/strip Rr Dr Rh  
 W/strip Rr Dr Lh  
 Mld Rr Dr Rh Low  
 Mld Rr Dr Lh Low  
 Emblem-trunk Lide  
 Bracket-rear Bumper Side,rh  
 Belt Assy-tongue,pre Fr Rh  
 Belt Assy-tongue,pre Fr Lh  
 Switch Assy Frt Seat  
 Knob Rr Seat Lock  
 Cover B/d Finisher  
 Condenser Assy  
 Tank Assy Liquid  
 Valve Assy Expansion  
 Tube Fr Cooler  
 Mirror Assy-door,rh  
 Mirror Assy-door,lh  
 Mirror Under Frt  
 Cover-mirror Body,rh  
 Cover-mirror Body,lh  
 Gasket Set Eng O/h  
 Body Combi Switch  
 Kit Lamp Rh  
 Kit Lamp Lh  
 Emblem 2.5 Xt  
 Key Blank Master  
 Sensor Air Bag

### ALL NEW X-TRAIL (T32N)

Belt Fan & Alt  
 Oil Filter  
 Air Filter  
 Spark Plug  
 Filter Air Cabin  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Mtf  
 Cvtf  
 Gasket Ins Carb  
 Gasket Int Manifold  
 Gasket Oil Pan Plug  
 Brake Pad  
 Brake Shoe Set  
 Seal Kit Fr Disc Brake  
 Disc Assy-clutch  
 Clutch Cover  
 Cylinder Assy Cl/opr  
 Strut Kit Frt Susp Rh  
 Strut Kit Frt Susp Lh  
 Shock Absorber Rr  
 Insulator Eng Mtg Frt  
 Engine Mount Insulator  
 Water Pump  
 Thermostat  
 Radiator  
 Radiator Hose  
 Ignition Coil  
 Seal Oil Crank Shaft Rr  
 Gasket Rocker Cover  
 Seal Oil Crank Shaft Fr

Cap A Radiator Filler  
 Alternator  
 Blade Assy W/shield Driver  
 Blade Assy W/shield Assist  
 Glass Mirror Rh  
 Glass Mirror Lh  
 Socket Tie Rod Otr  
 Bush Stabilizer  
 Rod Assy Conn Stab  
 Fuse 5 A  
 Fuse 30 A  
 Fuse (Small) 20a  
 Bohlamp Rem  
 Bohlamp Sign  
 Bohlamp Mundur  
 Bulb Headlamp  
 Battery Key Alarm  
 Bulb Fog Lamp  
 Refill-wiper Blade,driver  
 Refill-wiper Blade Assist  
 Clip  
 Bmpr-f/filler Lid  
 Plug Body Sill  
 Dowel Camshaft  
 Tube-spark Plug  
 Brkt Assy  
 Buffer Assy-rr  
 Valve Assy Control  
 Bearing Cr/s  
 Cover A Vlv Rocker  
 Mtg-air Clnr,rub  
 Resonator Assy  
 Insulator Exh Mtg  
 Gasket Exh Pipe  
 Shroud Assy W/motor  
 Shroud Assy  
 Tank Assy-reserve  
 Cap Tank Reserv  
 Air Fuel Ratio Sensor  
 Crankshaft Position  
 Connector Assy 18.00mm  
 Housing-fusible Link Holder  
 Bar Battery  
 Rod Battery Fix  
 Sensor-oil Pressure  
 Relay Ign  
 Sw Assy-stop Lamp  
 Switch Assy-door  
 Switch Assy Mirror  
 Horn Assy L/tone  
 Horn Assy H/tone  
 Relay Assy Horn  
 Lamp Assy Head Rh  
 Lamp Assy Head Lh  
 Lamp Assy Side Flasher  
 Lamp Assy Rr Comb Rh  
 Lamp Assy Rr Comb Lh  
 Reflector Rr  
 Control Assy A/c  
 Sensor Assy-sonar Silver  
 Control Unit-ipdm Engine Room  
 Controller Assy-sonar  
 Finisher-sonar White  
 Cover Rr Wiper Arm  
 Cover-wiper Arm  
 Cap W/s Washer Tank  
 Pump Assy-washer  
 Plate-cable Lock  
 Shaft Assy Frt Drv Rh  
 Shaft Assy Frt Drv Lh  
 Valve-air  
 Ornament Disc Wheel  
 Spr-lock,brake Hose  
 Sensor A/anti Skid Frt  
 Sensor Assy-height,front  
 Spring Seat

Link Assy Transv Rh  
 Link Assy Transv Lh  
 Stabilizer Bar Frt  
 Seat Spring Rr  
 Bumper Suspens  
 Link Compl-stab Rr,rh  
 Link Compl-stab Rr,lh  
 Reinforce Frt Bmp  
 Cover-bumper Bracket  
 Grommet  
 Emblem Rad Grille  
 Protr Assy-fr Fdr,rh  
 Protr Assy-fr Fdr,lh  
 Mud Guard Frt Rh  
 Mud Guard Frt Lh  
 Rub Seal Hood F  
 Bumper Hood  
 Insulator-hood  
 Grom-ptn Pipe  
 Garnish Assy-front Pillar,rh  
 Garnish Assy-front Pillar,lh  
 Moulding Frt Dr Rh  
 Moulding Frt Dr Lh  
 Link-door Stopper  
 Grip Out Side  
 Eschuteon Out  
 Tape-front Door Sash Rear,rh  
 Tape-front Door Sash Rear,lh  
 Moulding Frt Dr Otr Rh  
 Moulding Frt Dr Otr Lh  
 Rubber Bumper  
 Grom  
 Mld Fr Dr Rh Low  
 Mld Fr Dr Lh Low  
 Cap Pull Handle  
 Moulding Rr Dr Sash Rh  
 Moulding Rr Dr Sash Lh  
 Glass Run-rr Door Wdw,rh  
 Glass Run-rr Door Wdw,lh  
 Tape-rr Door Sash, Rh  
 Tape-rr Door Sash, Lh  
 Tape-rr Door,rh  
 Tape-rr Door,lh  
 Moulding-rear Door Outside,rh  
 Moulding-rear Door Outside,lh  
 Mld Rr Dr Rh Low  
 Mld Rr Dr Lh Low  
 Protector Dr Rr Rh  
 Protector Dr Rr Lh  
 Reinf-bumper Rr  
 Bracket-rear Bumper Side,rh  
 Bracket-rear Bumper Side,lh  
 Knob-switch,rh  
 Knob-switch,lh  
 Fin Assy Back Door  
 Condenser Assy  
 Sensor Assy-pressuree  
 Valve Assy Expansion  
 Tube Fr Cooler  
 Compressor A/c  
 Mirror Assy-door,rh  
 Mirror Assy-door,lh  
 Cover-mirror Body,rh  
 Cover-mirror Body,lh  
 Sensor Diagnosis A/bag  
 Dam Rubber-sealant  
 Safety Triangle  
 Stay-rr Bumper  
 Module Assy-air Bag,driver  
 Module Assy-air Bag,assist

### JUKE (F15N)

Belt Fan & Alt  
 Oil Filter  
 Air Filter  
 Spark Plug

Filter Air Cabin  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Cvtf  
 Gasket Int Manifold  
 Gasket Oil Pan Plug  
 Brake Pad  
 Brake Shoe Set  
 Seal Kit Fr Disc Brake  
 Strut Kit Frt Susp Rh  
 Strut Kit Frt Susp Lh  
 Shock Absorber Rr  
 Insulator Eng Mtg Frt  
 Engine Mount Insulator  
 Water Pump  
 Thermostat  
 Radiator Hose  
 Ignition Coil  
 Seal Oil Crank Shaft Rr  
 Gasket Rocker Cover  
 Seal Oil Crank Shaft Fr  
 Cap A Radiator Filler  
 Blade Assy W/shield Driver  
 Blade Assy W/shield Assist  
 Glass Mirror Rh  
 Glass Mirror Lh  
 Bush Stabilizer  
 Rod Assy Conn Stab  
 Fuse 10 A  
 Fuse 15 A  
 Fuse 20 A  
 Fuse (Small) 10a  
 Fuse (Small) 15a  
 Fuse (Small) 20a  
 Bohlamp Rem  
 Bohlamp Sign  
 Bohlamp Mundur  
 Bulb Headlamp  
 Bohlamp Battery Key Alarm  
 Refill-wiper Blade,driver  
 Refill-wiper Blade Assist  
 Pan Assy Oil  
 Support-engine Mounting,lh  
 Bearing-connecting Rod  
 Cover A Vlv Rocker  
 Duct-air  
 Injector Assy Fuel  
 Tube Assy-filler  
 Hose-radiator,lower  
 Tank Assy-reserve  
 Protector Ign Coil  
 Motor Starter  
 Valve A/solenoid  
 Terminal Assy-battery\_16.60mm  
 Cover-fusible Link Holder  
 Combination Meter  
 Sensor-oil Pressure  
 Switch Assy-power Window,main  
 Switch Assy-power Window,assis  
 Switch Assy-comb W/o Fog Lamp  
 Horn Assy L/tone  
 Horn Assy H/tone  
 Lamp Assy Head Rh  
 Lamp Assy Head Lh  
 Lamp Assy Rr Comb Rh  
 Lamp Assy Rr Comb Lh  
 Motor Blower  
 Controller Assy  
 Control Unit-ipdm Engine Room  
 Switch Assy-smart Keyless  
 Arm Assy Rr Wdw Wiper  
 Cover-wiper Arm  
 Cap W/s Washer Tank  
 Pump Assy-washer  
 Gasket-oil Pan

Hub Assy Frt Wheel  
Valve-air  
Caliper Assy-fr Rh W  
Caliper Assy-fr Lh W  
Hub Assy-rear  
Joint Assy Strg Shaft  
Lock Assy-steering  
Stopper Rub-fr  
Rubber-end  
Grille-radiator  
Bracket-front Bumper Side,rh  
Bracket-front Bumper Side,lh  
Cover-bumper Bracket  
Guide-rh  
Protr Assy-fr Fdr,rh  
Protr Assy-fr Fdr,lh  
Moulding-fillet,front Rh  
Moulding-fillet,front Lh  
Cover-front Fender,rh  
Cover-front Fender,lh  
Moulding Set W/shield  
Duct-drafter  
Mudguard Sill Ctr Rh  
Mudguard Sill Ctr Lh  
Hook  
Regulator Assy-door Window,rh  
Regulator Assy-door Window,lh  
Hinge Assy Front Door Lower  
Hinge Assy Front Door Upper  
Check Assy Rr Dr  
Tape-rr Door,rh  
Tape-rr Door,lh  
Plate Luggage Rear  
Belt Assy-tongue,pre Fr Rh  
Belt Assy-tongue,pre Fr Lh  
Finisher Seat Belt  
Protect Rr Seat Lock Rh  
Protect Rr Seat Lock Lh  
Stay Assy-back Door,rh  
Stay Assy-back Door,lh  
Bumper-rubber  
Emblem Rr Back Dr  
Condenser Assy  
Tank Assy Liquid  
Hose Flex Low  
Compressor A/c  
Cover-mirror Body,rh  
Cover-mirror Body,lh  
Sunvisor Assy-rh  
Sunvisor Assy-lh  
Holder Sunvisor  
Bulb Indicator  
Lamp Assy Fog R/l  
Sensor Diagnosis A/bag  
Repair Kit Dust Boot  
Side Window Sticker Kit White  
Key Blank Master  
Module Assy-air Bag,driver  
Module Assy-air Bag,assist  
Sensor Air Bag

### SERENA (C24N)

Belt Fan & Alt  
Oil Filter  
Air Filter  
Spark Plug  
Filter Air Cabin  
Engine Oil  
Brake Fluid  
Long Life Coolant  
Atf  
Gasket Oil Pan Plug  
Brake Pad  
Brake Shoe Set  
Seal Kit Fr Disc Brake  
Strut Kit Frt Susp Rh

Strut Kit Frt Susp Lh  
Shock Absorber Rr  
Insulator Eng Mtg Frt  
Engine Mount Insulator  
Water Pump  
Thermostat  
Radiator Hose  
Ignition Coil  
Seal Oil Crank Shaft Rr  
Gasket Rocker Cover  
Cap A Radiator Filler  
Blade Assy W/shield Driver  
Blade Assy W/shield Assist  
Glass Mirror Rh  
Glass Mirror Lh  
Bush Stabilizer  
Rod Assy Conn Stab  
Fuse (Small) 10a  
Fuse (Small) 15a  
Fuse (Small) 20a  
Bohlamp Rem  
Bohlamp Mundur  
Bulb Headlamp  
Battery Key Alarm  
Bulb Fog Lamp  
Refill-wiper Blade,driver  
Refill-wiper Blade Assist  
Clip  
Gasket Kit-engine Repair  
Ring Set Piston 0.20 (4)  
Seal Oil Vlv Stem  
Duct Assy A/cleaner  
Tank Assy Fuel  
Gasket Exh Pipe  
Fan Cooling (5)  
Hose-radiator,lower  
Insulator Rad Mtg  
Hose A/t Cooler  
Tank Assy-reserve  
Regulator Assy Press  
Body Comb Switch  
Lamp Assy Head Rh  
Lamp Assy Head Lh  
Lamp Assy Frt Sgn Rh  
Lamp Assy Frt Sgn Lh  
Lamp Assy Side Flasher  
Printboard Assy Up Cr  
Refill Rr Wiper Blade  
Cover-wiper Arm  
Seal Oil Diff Side  
Valve-air  
Ornament Disc Wheel  
Cyl Assy Rr Wheel  
Hose P/s Return  
Tube Assy P/s  
Bumper Assy Bound  
Rod Assy Conn Stab Lh  
Arm Assy Rr Susp Rh  
Arm Assy Rr Susp Lh  
Finisher Frt Fascia Rh  
Finisher Frt Fascia Lh  
Protr Assy-fr Fdr,rh  
Protr Assy-fr Fdr,lh  
Splash Guard Rh  
Splash Guard Lh  
Hanger Coat  
Cover Fr Under  
Alarm Security System  
Rubber Bumper  
Door Bmp Rubber  
Lock & Remote Control Assy-rr Door  
Actuator Slide Dr Lock  
Bush Hinge  
Stay Assy-back Door,rh  
Tank Assy Liquid  
Compressor A/c

Mirror Assy-door,rh  
Mirror Assy-door,lh  
Power Fold Rh  
Power Fold Lh  
Guide Cable  
Key Blank Master

### NEW SERENA (C26N)

Belt Fan & Alt  
Oil Filter  
Air Filter  
Spark Plug  
Filter Air Cabin  
Engine Oil  
Brake Fluid  
Long Life Coolant  
Cvtf  
Gasket Oil Pan Plug  
Brake Pad  
Brake Shoe Set  
Seal Kit Fr Disc Brake  
Strut Kit Frt Susp Rh  
Strut Kit Frt Susp Lh  
Shock Absorber Rr  
Insulator Eng Mtg Frt  
Engine Mount Insulator  
Water Pump  
Thermostat  
Radiator Hose  
Ignition Coil  
Seal Oil Crank Shaft Rr  
Gasket Rocker Cover  
Seal Oil Crank Shaft Fr  
Cap A Radiator Filler  
Blade Assy W/shield Driver  
Blade Assy W/shield Assist  
Glass Mirror Rh  
Glass Mirror Lh  
Socket Tie Rod Otr  
Socket Tie Rod Inn  
Bush Stabilizer  
Rod Assy Conn Stab  
Fuse 15 A  
Fuse (Small) 10a  
Bohlamp Rem  
Bohlamp Sign  
Bohlamp Mundur  
Bulb Headlamp  
Battery Key Alarm  
Bulb Fog Lamp  
Refill-wiper Blade,driver  
Refill-wiper Blade Assist  
Clip  
Clip-trim  
Pan Assy Oil  
Rod Assy-pull D  
Valve Assy Control  
Tensioner Assy  
Bearing-connecting Rod  
Cover A Vlv Rocker  
Gasket-oil Pump To Cylinder  
Gasket Exh Pipe  
Shroud Assy W/motor  
Shroud Assy  
Fan Cooling (5)  
Motor Assy Fan  
Air Fuel Ratio Sensor  
Link Fusible 50a  
Relay Ign  
Switch Assy-power Window,main  
Fog Lamp Assy-rh  
Lamp Assy Side Flasher  
Bulb Lamp Assy Map  
Lamp Assy Rr Comb Rh  
Lamp Assy Rr Comb Lh

Reflextor Rr  
Motor Blower  
Switch Assy-smart Keyless  
Tank Assy W/washer  
Seal Oil  
Hub Assy Frt Wheel  
Valve-air  
Ornament Disc Wheel  
Sensor A/anti Skid Rr  
Joint Assy Strg Shaft  
Moulding Front Bumper  
Bracket-front Bumper Side,rh  
Bracket-front Bumper Side,lh  
Finisher Frt Fascia Rh  
Finisher Frt Fascia Lh  
Grille Radiator  
Midg-rad Grille Lower  
Air Guide Front  
Emblem Rad Grille  
Adapter Emblem  
Air Spoiler-front,rh  
Air Spoiler-front,lh  
Insulator-hood  
Moulding Assy-roof Side,rh  
Moulding Assy-roof Side,lh  
Cover Engine Lower  
Drafter-air  
Cap-kicking Plate,rh  
Cap-kicking Plate,lh  
Mud Guard Rr Rh  
Mud Guard Rr Lh  
Bumper-slide Door  
Board Assy Luggage Floor  
Slide Assy-2nd Seat,rh  
Slide Assy-2nd Seat,lh  
Cover Side Rail  
Drive Unit Assy-auto Slide  
Sensor Eye  
Module Parking  
Repair Kit Dust Boot  
Module Assy-air Bag,driver  
Module Assy-air Bag,assist  
Sensor Air Bag

### EVALIA (M20N)

Belt Fan & Alt  
Oil Filter  
Air Filter  
Spark Plug  
Filter Air Cabin  
Engine Oil  
Brake Fluid  
Long Life Coolant  
Mtf  
Atf  
Gasket Int Manifold  
Gasket Oil Pan Plug  
Brake Pad  
Brake Shoe Set  
Seal Kit Fr Disc Brake  
Disc Assy-clutch  
Clutch Cover  
Cylinder Assy Cl/opr  
Strut Kit Frt Susp Rh  
Strut Kit Frt Susp Lh  
Shock Absorber Rr  
Insulator Eng Mtg Frt  
Engine Mount Insulator  
Fuel Pump  
Water Pump  
Thermostat  
Radiator  
Radiator Hose  
Ignition Coil  
Seal Oil Crank Shaft Rr  
Gasket Rocker Cover

Seal Oil Crank Shaft Fr  
Cap A Radiator Filler  
Blade Assy W/shield Driver  
Blade Assy W/shield Assist  
Glass Mirror Rh  
Glass Mirror Lh  
Bush Stabilizer  
Rod Assy Conn Stab  
Fuse (Small) 10a  
Fuse (Small) 15a  
Fuse (Small) 20a  
Bohlamp Rem  
Bohlamp Sign  
Bohlamp Mundur  
Bulb Headlamp  
Battery Key Alarm  
Bulb Fog Lamp  
Refill-wiper Blade,driver  
Refill-wiper Blade Assist  
Clip  
Pan Assy Oil  
Brkt Assy-eng Mtg,fr  
Support-engine Mounting,lh  
Buffer Assy-rr  
Hose-blowby Gas  
Bushing Crank  
Flywheel Assy  
Sprocket Cr/shaft  
Tensioner Assy-chain  
Guide-chain,tension Side  
Valve-exhaust  
Cover A Vlv Rocker  
Gasket-oil Pump To Cylinder  
Air Cleaner Cover  
Tank Assy Fuel  
Mfr Assy-exh,main  
Bearing Seal  
Ring Rubber  
Shroud Assy  
Hose-radiator,lower  
Insulator Rad Mtg  
Tank Assy-reserve  
Control Unit Eng  
Cover-fusible Link Holder  
Combination Meter  
Sender Unit Fuel  
Switch Assy-power Window,main  
Switch Assy T/sign  
Switch Assy Mirror  
Horn Assy L/tone  
Resistance Elect  
Amplifier Assy-thermo  
Cover Usrm  
Switch Assy-smart Keyless  
Arm Assy Rr Wdw Wiper  
Cap W/s Washer Tank  
Gasket Side Cover  
Bearing Needle  
Seal Lip  
Plate A Drive  
Switch Inhibitor  
Sensor Assy Revolution  
Solenoid A/t Control  
Pipe-breather  
Pinion Speedometer  
Hub Assy Frt Wheel  
Valve-air  
Tire Dunlop  
Case Assy Rr Axle  
Hub Assy-rear  
Insulator  
Sensor A/anti Skid Rr  
Joint Assy Strg Shaft  
Fixer-strg Lock  
Insulator Assy Strut Mtg  
Bearing Strut Mtg

Stay Assy-fr Susp Mbr  
 Link Assy Transv Rh  
 Link Assy Transv Lh  
 Bush-rr Spr,rr Upr  
 Bush-rr Spr,rr Lwr  
 Reinforce Frt Bmp  
 Grille Radiator  
 Air Guide Front  
 Guide-air,fr Lh  
 Emblem Rad Grille  
 Protr Assy-fr Fdr,rh  
 Protr Assy-fr Fdr,lh  
 Fin Assy-fr Fdr,rh  
 Fin Assy-fr Fdr,lh  
 Male Assy Hood Lock  
 Grom Hood Rodd  
 Rub-bmpr,hood  
 Panel Assy-inst Lwr  
 Cover Assy-fr Under  
 Drafter-air  
 Glass Run-fr Door Wdw,rh  
 Glass Run-fr Door Wdw,lh  
 Link-door Stopper  
 Lock & Remote Control  
 Tape-front Door Sash Rear,rh  
 Tape-front Door Sash Rear,lh  
 W/strip Frt Dr Rh  
 W/strip Frt Dr Lh  
 Roller Assy-slide Door Rear,rh  
 Roller Assy-slide Door,rear Lh  
 Bumper-slide Door  
 Fin Assy-lug Side,lwr Rh  
 Fin Assy-lug Side,lwr Lh  
 Plate Luggage Rear  
 Belt Assy-tongue,pre Fr Rh  
 Belt Assy-tongue,pre Fr Lh  
 Stay Assy-back Door,rh  
 Stay Assy-back Door,lh  
 Lock Assy Back Door  
 Emblem B/door "Evalia"  
 Handle-pull,back Door  
 Condenser Assy  
 Mounting Rob Cond  
 Tank Assy Liquid  
 Valve Assy Expansion  
 Pipe Assy-rr Cooler,low A  
 Sunvisor Assy-rh  
 Sunvisor Assy-lh  
 Gasket Set Eng O/h  
 Bushing Set Us=0.25  
 Body Combi Switch  
 Dam Rubber-sealant  
 Mudguard Rr Rh  
 Mudguard Rr Lh  
 Sensor Air Bag

### NAVARA (D40T)

Belt Fan & Alt  
 Oil Filter  
 Air Filter  
 Filter Air Cabin  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Mtf  
 Atf  
 Diff Hyp Ls 85w-90 GI5+ls  
 Filter Fuel Cartr  
 Gasket Oil Pan Plug  
 Brake Pad  
 Brake Master Cylinder  
 Disc Assy-clutch  
 Shock Absorber Rr  
 Insulator Eng Mtg Frt  
 Radiator  
 Alternator

Glass Mirror Rh  
 Glass Mirror Lh  
 Socket Tie Rod Otr  
 Bush Stabilizer  
 Refill-wiper Blade,driver  
 Refill-wiper Blade Assist  
 Gasket Kit-engine Repair  
 Gasket-cylinder Head  
 Tube-spark Plug  
 Insulator Eng Mtg Rr  
 Belt A/c Compressor  
 Pulley Idler Compr  
 Ring Set Piston Std  
 Flywheel Assy  
 Gear Camshaft  
 Tensioner Assy-chain  
 Guide-chain,tension Side  
 Valve Intake  
 Valve-exhaust  
 Seal Oil Vlv Stem  
 Cover A Vlv Rocker  
 Gasket R/arm Cover  
 Ornament Manifold  
 Turbo Charger  
 Gasket Inlet Tube  
 Gasket Adapter  
 Valve Solenoid  
 Coupling Assy Fan  
 Shroud Rad Upper  
 Pulley Assy Alt  
 Motor Starter  
 Crankshaft Position  
 Holder Link Fusible  
 Sender Unit Fuel  
 Switch Assy-power Window,main  
 Lamp Assy Head Rh  
 Lamp Assy Head Lh  
 Lamp Assy Licence  
 Lamp Assy Rr Comb Rh  
 Lamp Assy Rr Comb Lh  
 Resistance Elect  
 Seal Oil  
 Blank Valve Assy A/t Ctrl  
 Seal-oil,rear  
 Journal Kit  
 Seal Oil Diff Side  
 Repair Kit-dust Boot,outer  
 Hub Assy Frt Wheel  
 Seal Dust  
 Gear & Link Assy Strg  
 Spring Seat  
 Link Assy Transv Rh  
 Bushing Radius Rod  
 Bush-rr Spr,rr Lwr  
 Bracket Bmp Mtg  
 Emblem Rad Grille  
 Bumper Rubr E/hood  
 Rod-hood Support  
 Grom Hood Rodd  
 Insulator-hood  
 Moulding W/s Upp  
 Regulator Assy-door Window,rh  
 Regulator Assy-door Window,lh  
 Motor Assy-regulator,rh  
 Motor Assy-regulator,lh  
 Bumper Rear Ctr  
 Lock Assy Back Door  
 Condenser Assy  
 Mtg Rubb Body Lwr  
 Mirror Assy-door,rh  
 Mirror Assy-door,lh  
 Retainer Console Booth  
 Key Blank Master

### ALL NEW NAVARA (D23T)

Oil Filter  
 Air Filter  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Mtf  
 Atf  
 Diff Hyp Ls 85w-90 GI5+ls  
 Nissan Diff Gear Oil  
 Filter Fuel Cartr  
 Gasket Oil Pan Plug  
 Shock Absorber Rr  
 Insulator Eng Mtg Frt  
 Socket Tie Rod Otr  
 Bush Stabilizer  
 Clip  
 Clip-trim  
 Gear Camshaft  
 Tensioner Assy-chain  
 Guide-chain,tension Side  
 Seal Oil Vlv Stem  
 Filter Double Kit  
 Pre Filter  
 Clip-hose  
 Insulator Rad Mtg  
 Sensor Assy Temp  
 Crankshaft Position  
 Relay Ign  
 Switch Assy-door  
 Relay Assy Horn  
 Bulb-wedge Base  
 Lamp Assy Rr Comb Rh  
 Lamp Assy Rr Comb Lh  
 Seal Oil  
 Journal Kit  
 Seal Oil Diff Side  
 Seal Dust  
 Gasket Conn  
 Spring Seat  
 Protr Assy-fr Fdr,rh  
 Protr Assy-fr Fdr,lh  
 Grom Hood Rodd  
 Mtg Rubb Body Lwr  
 Air Spoiler-front,center Lower  
 Air Spoiler Assy-rear  
 Label-name,body Side

### ELGRAND (E52)

Oil Filter  
 Air Filter  
 Spark Plug  
 Filter Air Cabin  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Cvtf  
 Throttle Body Gasket  
 Gasket-adapter  
 Gasket Oil Pan Plug  
 Brake Pad  
 Disc Brake Rotor Fr  
 Strut Kit Frt Susp Rh  
 Strut Kit Frt Susp Lh  
 Shock Absorber Rr  
 Socket Tie Rod Inn  
 Bush Stabilizer  
 Refill-wiper Blade,driver  
 Refill-wiper Blade Assist  
 Insulator Eng Mtg Rr  
 Air Fuel Ratio Sensor  
 Pulley Assy Alt  
 Lamp Assy Side Flasher  
 Lamp Assy Rr Comb Rh  
 Lamp Assy Rr Comb Lh

Blower Assy-rear  
 Ornament Disc Wheel  
 Hose Control  
 Mirror Assy-door,rh  
 Mirror Assy-door,lh  
 Sealant Set-tyr

### TEANA (J31)

Oil Filter  
 Air Filter  
 Spark Plug  
 Filter Air Cabin  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Atf  
 Gasket Oil Pan Plug  
 Insulator Eng Mtg Frt  
 Insulator Eng Mtg Rr  
 Belt A/c Compressor  
 Belt Power Steering  
 Seal Oil Cr/shaft  
 Gasket Exh Pipe  
 Insulator Rad Mtg  
 Sensor Assy Temp  
 Bulb Lamp Assy Map  
 Mould Rr Bumper

### NEW TEANA (J32T)

Oil Filter  
 Air Filter  
 Spark Plug  
 Filter Air Cabin  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Cvtf  
 Gasket Oil Pan Plug  
 Strut Kit Frt Susp Rh  
 Strut Kit Frt Susp Lh  
 Ignition Coil  
 Cap A Radiator Filler  
 Blade Assy W/shield Driver  
 Blade Assy W/shield Assist  
 Socket Tie Rod Otr  
 Socket Tie Rod Inn  
 Clip  
 Clip-hose,spr Plate  
 Switch Assy-smart Keyless  
 Repair Kit-dust Boot,outer  
 Repair Kit-dust B00t,inner  
 Rotor Disc Rr Brk  
 Joint Assy Strg Shaft  
 Joint Assy-steering,lower  
 Mldg Bmp Fr Rh  
 Mldg Bmp Fr Lh  
 Grille Radiator  
 Protr Assy-fr Fdr,rh  
 Protr Assy-fr Fdr,lh  
 Moulding W/s Upp  
 Bumper B/door  
 Emblem-trunk Lide  
 Mould Rr Bumper

### ALL NEW TEANA (L33T)

Oil Filter  
 Air Filter  
 Spark Plug  
 Filter Air Cabin  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Cvtf  
 Gasket Oil Pan Plug

Cover A Vlv Rocker  
 Lamp Assy Rr Comb Rh  
 Lamp Assy Rr Comb Lh  
 Insulator Assy Strut Mtg

### ALMERA (N17T)

Belt Fan & Alt  
 Oil Filter  
 Air Filter  
 Spark Plug  
 Filter Air Cabin  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Mtf  
 Gasket Ins Carb  
 Gasket Int Manifold  
 Gasket Oil Pan Plug  
 Insulator Eng Mtg Frt  
 Insulator Eng Mtg Rr  
 Valve Assy Control  
 Belt A/c Compressor  
 Gasket Egr C/valve  
 Shroud Assy W/motor  
 Bearing Assy-front Wheel  
 Caliper Assy-fr Rh W  
 Caliper Assy-fr Lh W  
 Cover-bumper Bracket  
 Grille Radiator  
 Moulding Set W/shield  
 Condenser Assy

### TERANO (D21)

Oil Filter  
 Air Filter  
 Spark Plug  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Nissan Diff Gear Oil  
 Mtf  
 Filter Fuel Cartr  
 Gasket Int Manifold  
 Gasket Oil Pan Plug  
 Clip  
 Gasket Kit-engine Repair  
 Gasket-cylinder Head  
 Gasket-water Outlet  
 Valve Intake  
 Seal Oil Vlv Stem  
 Gasket Fr Cover Rh  
 Gasket Fr Cover Lh  
 Hose Water  
 Connector Water  
 Cap Frt Door Hinge  
 Brg Kit Protr Ctr 4x2  
 Cup Kit Rr W/cyl

### FRONTIER (D22)

Oil Filter  
 Air Filter  
 Engine Oil  
 Brake Fluid  
 Long Life Coolant  
 Gasket Oil Pan Plug  
 Clutch Cover  
 Ring Set Piston Std  
 Seal Oil Cr/shaft Rr  
 Gear Ring F/whl  
 Seal Oil Rocker Arm  
 Rod Assy Relay